


IV. ON/OFF (SCOOTERS EQUIPPED WITH SMARTPHONE)

1.- To unlock the Scooter, press one of the green buttons of the application in your smartphone. The dashboard will turn on and the status indicator will appear in READY mode.



2.- To start the engine of the scooter, press the red switch to ON mode. You will see on the dashboard that the status of the scooter changes to ON.



3.-To turn off the engine of the scooter, press the switch from ON to OFF. The screen will display READY and, after some seconds, will turn off.

Beware! Although the dashboard turned off, the scooter will not be blocked, and therefore, by pressing ON again, the scooter would turn on and it could be driven.

4.- To lock the scooter, once you press the right button on OFF position (point 3 above), press the red button "Stop" of the application in your smartphone. The screen will display READY and, after some seconds, will turn off.

